

# FRAISES ROTATIVES SE – OVALES



## COUPE SIMPLE, COUPE DOUBLE ET BRISE-COPEAUX

Article	DE x LdC x DE de tige x Lt	Coupe simple Pièce No.	Coupe double Pièce No.	Brise-copeaux Pièce No.
SE-41M*	3 x 5.5 x 3 x 38	ES18-0501	<b>ES18-0502A</b>	ES18-0503
SE-41ML2*	3 x 5.5 x 3 x 50	ES18-0506	ES18-0507	ES18-0508
SE-41ML3*	3 x 5.5 x 3 x 75	ES18-0511	ES18-0512	ES18-0513
SE-51M	6.3 x 9.5 x 3 x 47	ES18-0516	ES18-0517	ES18-0518
SE-1M*	6 x 9.5 x 6 x 50	ES18-0521	<b>ES18-0522A</b>	ES18-0523
SE-1ML6	6 x 9.5 x 6 x 160	ES18-0526	ES18-0527	ES18-0528
SE-3M	9.5 x 16 x 6 x 60	ES18-0531	ES18-0532	ES18-0533
SE-3ML6	9.5 x 16 x 6 x 166	ES18-0536	ES18-0537	ES18-0538
SE-5M	12.7 x 22 x 6 x 66	ES18-0541	ES18-0542	ES18-0543
SE-5ML6	12.7 x 22 x 6 x 172	ES18-0546	ES18-0547	ES18-0548
SE-6M	16 x 25 x 6 x 69	ES18-0551	ES18-0552	ES18-0553
SE-7M	19 x 25 x 6 x 69	ES18-0556	ES18-0557	ES18-0558

CONTENTS

BASE COATINGS

ENDMILLS

MOLD &amp; DIE

ESX

ASX

THREADMILLS

BURS